Product Demo - Model No 8503

- Access and Attendance Reader
- Smart card OR Fingerprint
- DUAL Mode – Smartcard + fingerprint
- GPRS Enabled
- TCP/IP Enabled
- Attendance – Suitable at Office Entrances / Factory Gates
- Access- Suitable for Server Rooms, BPO, Call Centre, Sensitive areas

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

- Model 8503 is suited for Attendance and access purpose.
- Follow the steps to understand method of working of this SAVIOR reader.

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

Step 1

(Smart Card+ Finger)

- Use of Smart card by Staff / Employees
- Show the smart card on the front side of the SAVIOR Reader

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

Step 2

- Put the enrolled finger on sensor area.
- SAVIOR Readers are able to recognize Smart card and Finger Print DUAL Mode (Useful for sensitive areas / offices and control proxy punching

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

Step 3

- Name and Paycode will be displayed on SAVIOR Reader in case of Valid Punch.
- The User card no, Date / Time will be recorded in SAVIOR Reader
- Electro Magnetic lock is installed on doors to allow / disallow access will operate. (if used for Access)

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

Before

After lock is open

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

Step 4

- In case user is invalid Message is displayed
- Invalid attempt is recorded

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

(Only Finger)

Step 1

- Put the enrolled finger on sensor area. Reader sensor will glow.
- Reader will Identified Finger of User(Useful for sensitive areas / offices and control proxy punching

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

Step 2

- If user is valid Name is displayed
- The User card no, Date / Time is saved in the reader

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

Step 3

- In case user is invalid Message is displayed

Copyright 2011 – STJ Electronics P Ltd

Product Demo - Model No 8503

- Transfer of Data can be done at any time instance from SAVIOR Reader using appropriate communication channel.



- The data on PC is used by Software for reports and analysis for Access and Attendance.

Copyright 2011 – STJ Electronics P Ltd